

## Supporting Information

### Using machine learning to predict oxygen evolution activity for transition metal hydroxide electrocatalysts

Xue Jiang <sup>a,†</sup>, Yong Wang <sup>b,†</sup>, Baorui Jia <sup>b,\*</sup>, Xuanhui Qu <sup>b</sup>, Mingli Qin <sup>b,\*</sup>

<sup>a</sup> *Beijing Advanced Innovation Center for Materials Genome Engineering, Collaborative Innovation Center of Steel Technology, University of Science and Technology Beijing, Beijing, 100083, China*

<sup>b</sup> *Beijing Advanced Innovation Center for Materials Genome Engineering, Institute for Advanced Materials and Technology, University of Science and Technology Beijing, Beijing, 100083, China*

<sup>†</sup> *These two authors contribute equally to this work.*

<sup>\*</sup> *Corresponding author. jiabaorui@ustb.edu.cn (B. Jia), qinml@mater.ustb.edu.cn (M. Qin).*

## Synthesis

All hydroxide catalysts were synthesized using a modified aqueous sol-gel technique with metal chlorides as raw materials. The metal salts were weighed with the total metal ion amount of 0.27 mmol and dissolved in ethanol (4 ml) in a vial. Then a trace amount of deionized water (0.21 ml) was mixed with ethanol (2 ml) in another vial. After chilling, the solutions were mixed and propylene oxide (1 ml) was slowly added to the mixed solution. Thereafter, a wet gel was formed. The wet gel was aged for 24 h and soaked in acetone for another 5 days. Then the wet gel was dried in a vacuum at room temperature to obtain the final catalysts. For NiFeLa hydroxide, lanthanum nitrate was used as La source.

## Material characterization

The phases were characterized using XRD on a Rigaku D/max-RB12 diffractometer with Cu K $\alpha$  radiation in the 2- $\theta$  range of 5–90 °. XPS was performed on an X-ray photoelectron spectrometer (Thermo Escalab 250XI) using monochromatic Al K $\alpha$  radiation ( $h\nu=1486.6$  eV). SEM was conducted using an SU8100 electron microscope. TEM, HRTEM, and EDS mapping experiments were performed on a microscope (FEI Tecnai G2F30).

## Electrochemical characterization

All the electrochemical tests were performed using a typical three-electrode system with a 1 M KOH solution as the electrolyte, and a platinum foil and an Hg/HgO electrode as the counter and reference electrodes, respectively. To prepare the working electrode, 5 mg of the as-prepared catalyst, 0.8 mg conductive carbon, and 20  $\mu$ L of 5 wt.% Nafion solution were dispersed in a 980  $\mu$ L mixture of water and ethanol (water:ethanol = 1:1) under ultrasonication for at least 2 h to form a homogeneous catalyst ink. Subsequently, 4  $\mu$ L of the catalyst ink was cast onto a glassy carbon electrode (3 mm diameter). After drying at room temperature, the catalytic working electrode was used to perform the electrochemical study on an electrochemical workstation (CHI600E). The measured potentials vs. Hg/HgO were converted to potentials vs. RHE using the following equation:

$$E_{\text{RHE}} = E_{\text{Hg/HgO}} + 0.059\text{pH} + 0.098.$$

### **The original dataset**

The original data used in this work is collected and screened from published studies by experiment. The data set consists of 88 entries, shown in Table S1, covering the elemental composition in percent representing different hydroxide catalysts, the phase and morphology information of the sample, the measurement conditions including pH and electrode, and the target overpotential (OP) at 10 mA/cm<sup>2</sup>. The source references of published studies can also be found in Table S1. To make phase, morphology and electrode to be machine-readable, we give label encoding to these categorical variables. The encoding detail is shown in Table S2. In order to simplify the display of Table S1, we describe the values of phase, morphology and electrode in Table S1 in the encoded way.

Table S1. The collected and screened hydroxides catalyst from published studies by experiment (compositions in mole fraction).

<i>No.</i>	<i>Ni</i>	<i>Co</i>	<i>Fe</i>	<i>W</i>	<i>V</i>	<i>Ru</i>	<i>P</i>	<i>Au</i>	<i>Ce</i>	<i>Ir</i>	<i>Al</i>	<i>Mo</i>	<i>Zn</i>	<i>Mn</i>	<i>S</i>	<i>Se</i>	<i>Ti</i>	<i>Cr</i>	<i>Li</i>	<i>Pt</i>	<i>La</i>	<i>Morphology</i>	<i>Phase</i>	<i>pH</i>	<i>Electrode</i>	<i>Overpotential (mV)</i>	<i>Ref.</i>
<b>1</b>	0.97 1	0	0	0.02 9	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	2	13. 6	1	237	<sup>1</sup>
<b>2</b>	0.97 1	0	0	0.02 9	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	2	13. 6	1	264	<sup>1</sup>
<b>3</b>	0.75	0	0.12 5	0	0.12 5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	2	13. 6	3	200	<sup>2</sup>
<b>4</b>	0	0.66 4	0.33 2	0	0	0.00 4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	3	198	<sup>3</sup>
<b>5</b>	0	0.66 6	0.33 4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	3	310	<sup>3</sup>
<b>6</b>	0	0.75	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13	1	348	<sup>4</sup>
<b>7</b>	0.75	0	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13	1	404	<sup>4</sup>
<b>8</b>	0.39 7	0	0.59 6	0	0	0.00 7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0	13. 6	1	276	<sup>5</sup>
<b>9</b>	0.66 3	0	0.33 2	0	0	0.00 5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0	13. 6	1	207	<sup>5</sup>
<b>10</b>	0.83 3	0	0.16 7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	1	235	<sup>6</sup>
<b>11</b>	0.43 1	0.04 9	0.52	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	3	239	<sup>7</sup>
<b>12</b>	0.75	0	0.12 5	0	0.12 5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	231	<sup>8</sup>
<b>13</b>	0	0.4	0.1	0.4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	7	0	13. 6	2	250	<sup>9</sup>
<b>14</b>	0.18 7	0	0	0	0.74 8	0.06 5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	190	<sup>10</sup>

15	0.19 3	0	0	0	0.77	0.03 7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	180	10
16	0.2	0	0	0	0.8	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	200	10
17	0.73	0	0.26 6	0	0	0	0	0.00 4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	5	237	11
18	0.6	0	0.4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	1	227	12
19	0.92 1	0	0	0	0	0	0	0	0	0.07 9	0	0	0	0	0	0	0	0	0	0	0	0	2	0	13. 6	3	215	13
20	0.99 2	0	0	0	0	0	0	0	0	0.00 8	0	0	0	0	0	0	0	0	0	0	0	0	2	0	13. 6	3	338	13
21	0.95 4	0	0	0	0	0	0	0	0	0.04 6	0	0	0	0	0	0	0	0	0	0	0	0	2	0	13. 6	3	257	13
22	0	0	0.5	0	0	0	0	0	0	0	0	0	0	0	0	0.5	0	0	0	0	0	0	1	0	13. 6	4	287	14
23	0.9	0	0.05	0	0	0	0	0	0	0	0	0.0 5	0	0	0	0	0	0	0	0	0	0	1	0	13. 6	2	240	15
24	0	0.8	0	0	0	0	0	0	0	0	0	0	0.2	0	0	0	0	0	0	0	0	0	1	0	13. 6	1	235	16
25	0	0.50 5	0.49 5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	13	1	308	17
26	0.75	0	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	4	13. 6	2	215	18
27	0.6	0.4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13	2	420	19
28	0.07 5	0	0.16	0	0	0	0	0	0	0	0.76 5	0	0	0	0	0	0	0	0	0	0	0	1	3	13	1	275	20
29	0.22	0	0.44 7	0	0	0	0.33 3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	13. 6	2	260	21
30	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	170	22

31	0.5	0	0.5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13.6	7	199	23
32	0.5	0	0.5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	13.6	2	208	24
33	0.667	0	0.222	0	0	0	0	0	0	0	0	0	0	0.111	0	0	0	0	0	0	0	1	0	13.6	3	262	25
34	0.667	0	0	0	0	0	0.333	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	13.6	2	290	26
35	0	0.159	0.628	0	0	0	0	0	0	0	0	0	0	0	0.213	0	0	0	0	0	0	1	0	13.6	1	270	27
36	0.727	0.182	0.091	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13.6	1	224	28
37	0.909	0	0.091	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13.6	1	242	28
38	0.818	0.091	0.091	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13.6	1	232	28
39	0.6	0	0.4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	4	0	13	6	280	29
40	0.9	0	0.1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	4	0	13.6	6	336	30
41	0.88	0	0.12	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	4	0	13.6	6	280	31
42	0.8	0	0.2	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	5	1	13.6	1	215	32
43	0.78	0	0.22	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13.6	3	280	33
44	0.764	0	0.227	0	0	0	0	0	0	0	0	0	0	0	0	0	0.003	0	0	0	0.006	1	1	13.6	3	260	33
45	0.75	0	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	1	13.6	1	300	34
46	0.33	0.67	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	1	13.6	1	335	34

47	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	1	13. 6	1	350	34
48	0	0.25	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.5	0	0	1	0	13	3	350	35
49	0.16 5	0.16 5	0.16 5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.5	0	0	1	0	13	3	300	35
50	0.33	0.67	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	13. 6	0	360	36
51	0.33	0.67	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	5	1	13. 6	0	400	36
52	0.18 3	0.72 6	0.09 1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	3	280	37
53	0.2	0.8	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	3	330	37
54	0.61 1	0	0.20 4	0	0	0	0	0	0	0	0.18 5	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	300	38
55	0.56 9	0	0.19	0	0	0	0	0	0	0	0.24 1	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	323	38
56	0.44 5	0	0.14 9	0	0	0	0	0	0	0	0.40 6	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	327	38
57	0.5	0	0	0	0	0	0	0	0	0	0	0	0	0.5	0	0	0	0	0	0	0	1	1	13. 6	1	420	39
58	0.75	0	0	0	0	0	0	0	0	0	0	0	0	0.25	0	0	0	0	0	0	0	1	1	13. 6	1	350	39
59	0.76 7	0	0.10 6	0	0.12 7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	13. 6	2	192	40
60	0.83	0	0.17	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	13. 6	1	245	41
61	0.95	0	0	0	0	0	0	0	0.0 5	0	0	0	0	0	0	0	0	0	0	0	0	5	0	13. 6	6	271	42
62	0.67 8	0	0.31 5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.00 7	0	1	1	13. 6	1	230	43

63	0.75	0	0	0	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	1	13.6	1	218	44
64	0.75	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	1	13.6	1	347	44
65	0.75	0	0	0	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	1	13.6	2	300	44
66	0.615	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.385	0	0	0	0	1	0	13.6	1	320	45
67	0	0.2	0	0	0	0	0.6	0	0	0	0	0	0	0.2	0	0	0	0	0	0	0	6	0	13.6	4	288	46
68	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	6	0	13.6	4	408	46
69	0	0.25	0	0	0	0	0.75	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	13.6	4	322	46
70	0	0.4	0.3	0	0.3	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	5	0	13.6	1	307	47
71	0	0.6	0.4	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	4	0	13.6	3	283	48
72	0	0.33	0.67	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	5	0	13.6	1	314	49
73	0	0.67	0	0	0	0	0	0	0	0	0	0	0.33	0	0	0	0	0	0	0	0	2	0	13.6	1	324	50
74	0.33	0.67	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0	13.6	1	338	50
75	0	0.67	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.33	0	0	2	0	13.6	1	340	51
76	0	0.375	0.368	0.257	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	5	4	13.6	1	223	52
77	0	0.375	0.368	0.257	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	5	4	13.6	6	191	52
78	0	0.5	0.5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	1	13.	2	232	53



																								6				
79	0.5	0	0.5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	3	13. 6	1	280	54
80	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	2	0	13. 6	1	300	55	
81	0.75	0	0.25	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	5	0	13. 6	3	230	56	
82	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	6	0	13. 6	1	293	57	
83	0.36 4	0.22 7	0.40 9	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	6	0	13. 6	6	400	58	
84	0.16 7	0	0.16 7	0	0	0	0	0	0	0	0	0	0	0	0	0.66 6	0	0	0	0	0	5	0	13. 6	3	280	59	
85	0	0.66 7	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0.33 3	0	0	0	1	1	13	1	340	60	
86	0	0.66 7	0	0	0	0	0	0	0	0	0	0	0	0.33 3	0	0	0	0	0	0	0	2	1	13. 6	1	324	61	
87	0	0.74 1	0.25 9	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	13	1	350	62	
88	0	0.54	0.46	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	6	0	13	1	390	63	

Table S2. The label encoding method for the phase and morphology information of the sample and the measurement electrode.

Morphology		Phase		Electrode	
common plate	1	layered double hydroxide	1	glass carbon	1
exfoliated/ultrathin anosheet	2	$\alpha$ phase	2	Ni foam	2
porous sheet	3	$\gamma$ phase	3	carbon cloth/paper	3
film	4	amorphous phase	4	Iron foam	4
nanoparticle	5	unknown	0	Ti mesh	5
nanowire	6	-	-	Au/AuO/Pt supporter	6
flower	7	-	-	copper foam	7
unknown	0	-	-	unknown	0

### Data set after feature construction

Table S3. The data set in dense representation (compositions in mole fraction).

N o .	1 <sup>st</sup> _compo nentatom_ number	1 <sup>st</sup> _compone nt_element_ fraction	2 <sup>nd</sup> _compo nent_atom_ number	2 <sup>nd</sup> _compon ent_element_ fraction	3 <sup>rd</sup> _compo nent_atom_ number	3 <sup>rd</sup> _compon ent_element_ fraction	Mor phol ogy	P h as e	p H	Eel ectr ode	Over pote ntial (mV)	R e f.
1	28	0.971	74	0.029	0	0	2	2	1 3 . 6	1	237	<sup>1</sup>
2	28	0.971	74	0.029	0	0	1	2	1 3 . 6	1	264	<sup>1</sup>
3	28	0.75	26	0.125	23	0.125	1	2	1 3 . 6	3	200	<sup>2</sup>
4	27	0.664	26	0.332	44	0.004	1	1	1 3 . 6	3	198	<sup>3</sup>
5	27	0.666	26	0.334	0	0	1	1	1 3 . 6	3	310	<sup>3</sup>
6	27	0.75	26	0.25	0	0	1	1	1 3	1	348	<sup>4</sup>
7	28	0.75	26	0.25	0	0	1	1	1	1	404	<sup>4</sup>

									3			
8	28	0.397	26	0.596	44	0.007	2	0	1 3 . 6	1	276	<sup>5</sup>
9	28	0.663	26	0.332	44	0.005	2	0	1 3 . 6	1	207	<sup>5</sup>
1 0	28	0.833	26	0.167	0	0	1	1	1 3 . 6	1	235	<sup>6</sup>
1 1	28	0.431	26	0.52	27	0.049	1	1	1 3 . 6	3	239	<sup>7</sup>
1 2	28	0.75	26	0.125	23	0.125	1	1	1 3 . 6	2	231	<sup>8</sup>
1 3	27	0.4	74	0.4	26	0.1	7	0	1 3 . 6	2	250	<sup>9</sup>
1 4	23	0.748	28	0.187	44	0.065	1	1	1 3 . 6	2	190	<sup>10</sup>
1 5	23	0.77	28	0.193	44	0.037	1	1	1 3 . 6	2	180	<sup>10</sup>
1 6	23	0.8	28	0.2	0	0	1	1	1 3 . 6	2	200	<sup>10</sup>
1 7	28	0.73	26	0.266	79	0.004	1	1	1 3 . 6	5	237	<sup>11</sup>
1 8	28	0.6	26	0.4	0	0	1	1	1 3 .	1	227	<sup>12</sup>

									6			
1 9	28	0.921	77	0.079	0	0	2	0	1 3 . 6	3	215	<sup>13</sup>
2 0	28	0.992	77	0.008	0	0	2	0	1 3 . 6	3	338	<sup>13</sup>
2 1	28	0.954	77	0.046	0	0	2	0	1 3 . 6	3	257	<sup>13</sup>
2 2	26	0.5	34	0.5	0	0	1	0	1 3 . 6	4	287	<sup>14</sup>
2 3	28	0.9	26	0.05	42	0.05	1	0	1 3 . 6	2	240	<sup>15</sup>
2 4	27	0.8	30	0.2	0	0	1	0	1 3 . 6	1	235	<sup>16</sup>
2 5	27	0.505	26	0.495	0	0	1	0	1 3	1	308	<sup>17</sup>
2 6	28	0.75	26	0.25	0	0	1	4	1 3 . 6	2	215	<sup>18</sup>
2 7	28	0.6	27	0.4	0	0	1	1	1 3	2	420	<sup>19</sup>
2 8	13	0.765	26	0.16	28	0.075	1	3	1 3	1	275	<sup>20</sup>
2 9	26	0.447	15	0.333	28	0.22	1	0	1 3 . 6	2	260	<sup>21</sup>
3 0	28	1	0	0	0	0	1	1	1 3 . 6	2	170	<sup>22</sup>
3	28	0.5	26	0.5	0	0	1	1	1	7	199	<sup>23</sup>

1									3 . 6			
3 2	28	0.5	26	0.5	0	0	1	0	1 3 . 6	2	208	<sup>24</sup>
3 3	28	0.667	26	0.222	25	0.111	1	0	1 3 . 6	3	262	<sup>25</sup>
3 4	28	0.667	15	0.333	0	0	1	0	1 3 . 6	2	290	<sup>26</sup>
3 5	26	0.628	16	0.213	27	0.159	1	0	1 3 . 6	1	270	<sup>27</sup>
3 6	28	0.727	27	0.182	26	0.091	1	1	1 3 . 6	1	224	<sup>28</sup>
3 7	28	0.909	26	0.091	0	0	1	1	1 3 . 6	1	242	<sup>28</sup>
3 8	28	0.818	27	0.091	26	0.091	1	1	1 3 . 6	1	232	<sup>28</sup>
3 9	28	0.818	26	0.091	0	0	4	0	1 3	6	280	<sup>29</sup>
4 0	28	0.818	26	0.091	0	0	4	0	1 3 . 6	6	336	<sup>30</sup>
4 1	28	0.818	26	0.091	0	0	4	0	1 3 . 6	6	280	<sup>31</sup>
4 2	28	0.818	26	0.091	0	0	5	1	1 3 .	1	215	<sup>32</sup>

									6			
4 3	28	0.818	26	0.091	0	0	1	1	1 3 · 6	3	280	<sup>33</sup>
4 4	28	0.76389	26	0.22743	57	0.006	1	1	1 3 · 6	3	260	<sup>33</sup>
4 5	28	0.75	26	0.25	0	0	2	1	1 3 · 6	1	300	<sup>34</sup>
4 6	27	0.67	28	0.33	0	0	2	1	1 3 · 6	1	335	<sup>34</sup>
4 7	28	1	0	0	0	0	2	1	1 3 · 6	1	350	<sup>34</sup>
4 8	3	0.5	27	0.25	26	0.25	1	0	1 3	3	350	<sup>35</sup>
4 9	3	0.5	28	0.165	27	0.165	1	0	1 3	3	300	<sup>35</sup>
5 0	27	0.67	28	0.33	0	0	1	0	1 3 · 6	0	360	<sup>36</sup>
5 1	27	0.67	28	0.33	0	0	5	1	1 3 · 6	0	400	<sup>36</sup>
5 2	27	0.726	28	0.183	26	0.091	1	1	1 3 · 6	3	280	<sup>37</sup>
5 3	27	0.8	28	0.2	0	0	1	1	1 3 · 6	3	330	<sup>37</sup>
5 4	28	0.611	26	0.204	13	0.185	1	1	1 3 ·	2	300	<sup>38</sup>

									6			
5 5	28	0.569	13	0.241	26	0.19	1	1	1 3 · 6	2	323	<sup>38</sup>
5 6	28	0.445	13	0.406	26	0.149	1	1	1 3 · 6	2	327	<sup>38</sup>
5 7	28	0.5	25	0.5	0	0	1	1	1 3 · 6	1	420	<sup>39</sup>
5 8	28	0.75	25	0.25	0	0	1	1	1 3 · 6	1	350	<sup>39</sup>
5 9	28	0.7672	23	0.127	26	0.1058	1	1	1 3 · 6	2	192	<sup>40</sup>
6 0	28	0.83	26	0.17	0	0	1	0	1 3 · 6	1	245	<sup>41</sup>
6 1	28	0.95	58	0.05	0	0	5	0	1 3 · 6	6	271	<sup>42</sup>
6 2	28	0.678	26	0.315	78	0.007	1	1	1 3 · 6	1	230	<sup>43</sup>
6 3	28	0.75	23	0.25	0	0	2	1	1 3 · 6	1	218	<sup>44</sup>
6 4	28	0.75	27	0.25	0	0	2	1	1 3 · 6	1	347	<sup>44</sup>
6 5	28	0.75	23	0.25	0	0	2	1	1 3 ·	2	300	<sup>44</sup>

									6			
6 6	28	0.615	22	0.385	0	0	1	0	1 3 · 6	1	320	<sup>45</sup>
6 7	15	0.6	27	0.2	25	0.2	6	0	1 3 · 6	4	288	<sup>46</sup>
6 8	25	1	0	0	0	0	6	0	1 3 · 6	4	408	<sup>46</sup>
6 9	15	0.75	27	0.25	0	0	0	0	1 3 · 6	4	322	<sup>46</sup>
7 0	27	0.4	26	0.3	23	0.3	5	0	1 3 · 6	1	307	<sup>47</sup>
7 1	27	0.6	26	0.4	0	0	4	0	1 3 · 6	3	283	<sup>48</sup>
7 2	26	0.67	27	0.33	0	0	5	0	1 3 · 6	1	314	<sup>49</sup>
7 3	27	0.67	30	0.33	0	0	2	0	1 3 · 6	1	324	<sup>50</sup>
7 4	27	0.67	28	0.33	0	0	2	0	1 3 · 6	1	338	<sup>50</sup>
7 5	27	0.67	3	0.33	0	0	2	0	1 3 · 6	1	340	<sup>51</sup>
7 6	27	0.375	26	0.368	74	0.257	5	4	1 3 ·	1	223	<sup>52</sup>



									6			
7 7	27	0.375	26	0.368	74	0.257	5	4	1 3 · 6	6	191	<sup>52</sup>
7 8	27	0.5	26	0.5	0	0	2	1	1 3 · 6	2	232	<sup>53</sup>
7 9	28	0.5	26	0.5	0	0	2	3	1 3 · 6	1	280	<sup>54</sup>
8 0	27	1	0	0	0	0	2	0	1 3 · 6	1	300	<sup>55</sup>
8 1	28	0.75	26	0.25	0	0	5	0	1 3 · 6	3	230	<sup>56</sup>
8 2	27	1	0	0	0	0	6	0	1 3 · 6	1	293	<sup>57</sup>
8 3	26	0.409	28	0.364	27	0.227	6	0	1 3 · 6	6	400	<sup>58</sup>
8 4	34	0.666	28	0.167	26	0.167	5	0	1 3 · 6	3	280	<sup>59</sup>
8 5	27	0.667	24	0.333	0	0	1	1	1 3	1	340	<sup>60</sup>
8 6	27	0.667	25	0.333	0	0	2	1	1 3 · 6	1	324	<sup>61</sup>
8 7	27	0.741	26	0.259	0	0	0	1	1 3	1	350	<sup>62</sup>
8 8	27	0.54	26	0.46	0	0	6	0	1 3	1	390	<sup>63</sup>

## Reference

- (1) Yan, J.; Kong, L.; Ji, Y.; White, J.; Li, Y.; Zhang, J.; An, P.; Liu, S.; Lee, S. T.; Ma, T. Single atom tungsten doped ultrathin  $\alpha$ -Ni(OH)<sub>2</sub> for enhanced electrocatalytic water oxidation. *Nat Commun* **2019**, *10* (1), 2149. DOI: 10.1038/s41467-019-09845-z.
- (2) Jiang, J.; Sun, F.; Zhou, S.; Hu, W.; Zhang, H.; Dong, J.; Jiang, Z.; Zhao, J.; Li, J.; Yan, W.; et al. Atomic-level insight into super-efficient electrocatalytic oxygen evolution on iron and vanadium co-doped nickel (oxy)hydroxide. *Nat Commun* **2018**, *9* (1), 2885. DOI: 10.1038/s41467-018-05341-y.
- (3) Li, P.; Wang, M.; Duan, X.; Zheng, L.; Cheng, X.; Zhang, Y.; Kuang, Y.; Li, Y.; Ma, Q.; Feng, Z.; et al. Boosting oxygen evolution of single-atomic ruthenium through electronic coupling with cobalt-iron layered double hydroxides. *Nat Commun* **2019**, *10* (1), 1711. DOI: 10.1038/s41467-019-09666-0.
- (4) Dionigi, F.; Zeng, Z.; Sinev, I.; Merzdorf, T.; Deshpande, S.; Lopez, M. B.; Kunze, S.; Zegkinoglou, I.; Sarodnik, H.; Fan, D.; et al. In-situ structure and catalytic mechanism of NiFe and CoFe layered double hydroxides during oxygen evolution. *Nat Commun* **2020**, *11* (1), 2522. DOI: 10.1038/s41467-020-16237-1.
- (5) Kwon, N. H.; Kim, M.; Jin, X.; Lim, J.; Kim, I. Y.; Lee, N.-S.; Kim, H.; Hwang, S.-J. A rational method to kinetically control the rate-determining step to explore efficient electrocatalysts for the oxygen evolution reaction. *NPG Asia Materials* **2018**, *10* (7), 659-669. DOI: 10.1038/s41427-018-0060-3.
- (6) Gong, M.; Li, Y.; Wang, H.; Liang, Y.; Wu, J. Z.; Zhou, J.; Wang, J.; Regier, T.; Wei, F.; Dai, H. An advanced Ni-Fe layered double hydroxide electrocatalyst for water oxidation. *J Am Chem Soc* **2013**, *135* (23), 8452-8455. DOI: 10.1021/ja4027715.
- (7) Wang, A.-L.; Xu, H.; Li, G.-R. NiCoFe Layered Triple Hydroxides with Porous Structures as High-Performance Electrocatalysts for Overall Water Splitting. *ACS Energy Letters* **2016**, *1* (2), 445-453. DOI: 10.1021/acsenergylett.6b00219.
- (8) Dinh, K. N.; Zheng, P.; Dai, Z.; Zhang, Y.; Dangol, R.; Zheng, Y.; Li, B.; Zong, Y.; Yan, Q. Ultrathin Porous NiFeV Ternary Layer Hydroxide Nanosheets as a Highly Efficient Bifunctional Electrocatalyst for Overall Water Splitting. *Small* **2018**, *14* (8). DOI: 10.1002/sml.201703257.
- (9) Pi, Y.; Shao, Q.; Wang, P.; Lv, F.; Guo, S.; Guo, J.; Huang, X. Trimetallic Oxyhydroxide Coraloids for Efficient Oxygen Evolution Electrocatalysis. *Angew Chem Int Ed Engl* **2017**, *56* (16), 4502-4506. DOI: 10.1002/anie.201701533.
- (10) Wang, D.; Li, Q.; Han, C.; Lu, Q.; Xing, Z.; Yang, X. Atomic and electronic modulation of self-supported nickel-vanadium layered double hydroxide to accelerate water splitting kinetics. *Nat Commun* **2019**, *10* (1), 3899. DOI:

10.1038/s41467-019-11765-x.

- (11) Zhang, J. F.; Liu, J. Y.; Xi, L. F.; Yu, Y. F.; Chen, N.; Sun, S. H.; Wang, W. C.; Lange, K. M.; Zhang, B. Single-Atom Au/NiFe Layered Double Hydroxide Electrocatalyst: Probing the Origin of Activity for Oxygen Evolution Reaction. *Journal of the American Chemical Society* **2018**, *140* (11), 3876-3879. DOI: 10.1021/jacs.8b00752.
- (12) Xu, H.; Wang, B.; Shan, C.; Xi, P.; Liu, W.; Tang, Y. Ce-Doped NiFe-Layered Double Hydroxide Ultrathin Nanosheets/Nanocarbon Hierarchical Nanocomposite as an Efficient Oxygen Evolution Catalyst. *ACS Appl Mater Interfaces* **2018**, *10* (7), 6336-6345. DOI: 10.1021/acsami.7b17939.
- (13) Wang, Q.; Huang, X.; Zhao, Z. L.; Wang, M.; Xiang, B.; Li, J.; Feng, Z.; Xu, H.; Gu, M. Ultrahigh-Loading of Ir Single Atoms on NiO Matrix to Dramatically Enhance Oxygen Evolution Reaction. *J Am Chem Soc* **2020**, *142* (16), 7425-7433. DOI: 10.1021/jacs.9b12642.
- (14) Niu, S.; Jiang, W. J.; Wei, Z.; Tang, T.; Ma, J.; Hu, J. S.; Wan, L. J. Se-Doping Activates FeOOH for Cost-Effective and Efficient Electrochemical Water Oxidation. *J Am Chem Soc* **2019**, *141* (17), 7005-7013. DOI: 10.1021/jacs.9b01214.
- (15) Jin, Y. S.; Huang, S. L.; Yue, X.; Du, H. Y.; Shen, P. K. Mo- and Fe-Modified Ni(OH)(2)/NiOOH Nanosheets as Highly Active and Stable Electrocatalysts for Oxygen Evolution Reaction. *Acs Catalysis* **2018**, *8* (3), 2359-2363. DOI: 10.1021/acscatal.7b04226.
- (16) Huang, Z.-F.; Song, J.; Du, Y.; Xi, S.; Dou, S.; Nsanzimana, J. M. V.; Wang, C.; Xu, Z. J.; Wang, X. Chemical and structural origin of lattice oxygen oxidation in Co-Zn oxyhydroxide oxygen evolution electrocatalysts. *Nature Energy* **2019**, *4* (4), 329-338. DOI: 10.1038/s41560-019-0355-9.
- (17) Zhuang, L.; Ge, L.; Yang, Y.; Li, M.; Jia, Y.; Yao, X.; Zhu, Z. Ultrathin Iron-Cobalt Oxide Nanosheets with Abundant Oxygen Vacancies for the Oxygen Evolution Reaction. *Adv Mater* **2017**, *29* (17). DOI: 10.1002/adma.201606793.
- (18) Lu, X. Y.; Zhao, C. A. Electrodeposition of hierarchically structured three-dimensional nickel-iron electrodes for efficient oxygen evolution at high current densities. *Nat Commun* **2015**, *6*. DOI: ARTN 6616 10.1038/ncomms7616.
- (19) Jiang, J.; Zhang, A. L.; Li, L. L.; Ai, L. H. Nickel-cobalt layered double hydroxide nanosheets as high-performance electrocatalyst for oxygen evolution reaction. *J Power Sources* **2015**, *278*, 445-451. DOI: 10.1016/j.jpowsour.2014.12.085.
- (20) Zhou, Y.; Zeng, H. C. Adsorption and On-Site Transformation of Transition Metal Cations on Ni-Doped AlOOH Nanoflowers for OER Electrocatalysis. *Acs Sustain Chem Eng* **2019**, *7* (6), 5953-+. DOI:

10.1021/acssuschemeng.8b06020.

- (21) Li, Y. J.; Zhang, H. C.; Jiang, M.; Zhang, Q.; He, P. L.; Sun, X. M. 3D Self-Supported Fe-Doped Ni<sub>2</sub>P Nanosheet Arrays as Bifunctional Catalysts for Overall Water Splitting. *Adv Funct Mater* **2017**, *27* (37). DOI: ARTN 1702513 10.1002/adfm.201702513.
- (22) Rao, Y.; Wang, Y.; Ning, H.; Li, P.; Wu, M. B. Hydrotalcite-like Ni(OH)<sub>2</sub> Nanosheets in Situ Grown on Nickel Foam for Overall Water Splitting. *Acs Appl Mater Inter* **2016**, *8* (49), 33601-33607. DOI: 10.1021/acsami.6b11023.
- (23) Yu, L.; Zhou, H. Q.; Sun, J. Y.; Qin, F.; Yu, F.; Bao, J. M.; Yu, Y.; Chen, S.; Ren, Z. F. Cu nanowires shelled with NiFe layered double hydroxide nanosheets as bifunctional electrocatalysts for overall water splitting. *Energ Environ Sci* **2017**, *10* (8), 1820-1827. DOI: 10.1039/c7ee01571b.
- (24) Chi, J.; Yu, H. M.; Qn, B. W.; Fu, L.; Jia, J.; Yi, B. L.; Shao, Z. G. Vertically Aligned FeOOH/NiFe Layered Double Hydroxides Electrode for Highly Efficient Oxygen Evolution Reaction. *Acs Appl Mater Inter* **2017**, *9* (1), 464-471. DOI: 10.1021/acsami.6b13360.
- (25) Lu, Z.; Qian, L.; Tian, Y.; Li, Y.; Sun, X.; Duan, X. Ternary NiFeMn layered double hydroxides as highly-efficient oxygen evolution catalysts. *Chem Commun (Camb)* **2016**, *52* (5), 908-911. DOI: 10.1039/c5cc08845c.
- (26) Stern, L. A.; Feng, L. G.; Song, F.; Hu, X. L. Ni<sub>2</sub>P as a Janus catalyst for water splitting: the oxygen evolution activity of Ni<sub>2</sub>P nanoparticles. *Energ Environ Sci* **2015**, *8* (8), 2347-2351. DOI: 10.1039/c5ee01155h.
- (27) Du, J.; Zhang, T.; Xing, J.; Xu, C. Hierarchical porous Fe<sub>3</sub>O<sub>4</sub>/Co<sub>3</sub>S<sub>4</sub> nanosheets as an efficient electrocatalyst for the oxygen evolution reaction. *Journal of Materials Chemistry A* **2017**, *5* (19), 9210-9216. DOI: 10.1039/c7ta02108a.
- (28) Long, X.; Xiao, S.; Wang, Z.; Zheng, X.; Yang, S. Co intake mediated formation of ultrathin nanosheets of transition metal LDH-an advanced electrocatalyst for oxygen evolution reaction. *Chem Commun (Camb)* **2015**, *51* (6), 1120-1123. DOI: 10.1039/c4cc08856e.
- (29) Louie, M. W.; Bell, A. T. An investigation of thin-film Ni-Fe oxide catalysts for the electrochemical evolution of oxygen. *J Am Chem Soc* **2013**, *135* (33), 12329-12337. DOI: 10.1021/ja405351s.
- (30) Trotochaud, L.; Ranney, J. K.; Williams, K. N.; Boettcher, S. W. Solution-cast metal oxide thin film electrocatalysts for oxygen evolution. *J Am Chem Soc* **2012**, *134* (41), 17253-17261. DOI: 10.1021/ja307507a.
- (31) Klaus, S.; Cai, Y.; Louie, M. W.; Trotochaud, L.; Bell, A. T. Effects of Fe Electrolyte Impurities on Ni(OH)<sub>2</sub>/NiOOH Structure and Oxygen Evolution Activity. *The Journal of Physical Chemistry C* **2015**, *119* (13), 7243-7254. DOI: 10.1021/acs.jpcc.5b00105.
- (32) Chen, R.; Sun, G.; Yang, C.; Zhang, L.; Miao, J.; Tao, H.; Yang, H.; Chen, J.; Chen, P.; Liu, B. Achieving stable and

- efficient water oxidation by incorporating NiFe layered double hydroxide nanoparticles into aligned carbon nanotubes. *Nanoscale Horiz* **2016**, *1* (2), 156-160. DOI: 10.1039/c5nh00082c.
- (33) Hunter, B. M.; Blakemore, J. D.; Deimund, M.; Gray, H. B.; Winkler, J. R.; Muller, A. M. Highly active mixed-metal nanosheet water oxidation catalysts made by pulsed-laser ablation in liquids. *J Am Chem Soc* **2014**, *136* (38), 13118-13121. DOI: 10.1021/ja506087h.
- (34) Song, F.; Hu, X. Exfoliation of layered double hydroxides for enhanced oxygen evolution catalysis. *Nat Commun* **2014**, *5*, 4477. DOI: 10.1038/ncomms5477.
- (35) Lu, Z.; Wang, H.; Kong, D.; Yan, K.; Hsu, P. C.; Zheng, G.; Yao, H.; Liang, Z.; Sun, X.; Cui, Y. Electrochemical tuning of layered lithium transition metal oxides for improvement of oxygen evolution reaction. *Nat Commun* **2014**, *5*, 4345. DOI: 10.1038/ncomms5345.
- (36) Fang, L.; Jiang, Z. Q.; Xu, H. T.; Liu, L.; Guan, Y. X.; Gu, X.; Wang, Y. Crystal-plane engineering of NiCo<sub>2</sub>O<sub>4</sub> electrocatalysts towards efficient overall water splitting. *J Catal* **2018**, *357*, 238-246. DOI: 10.1016/j.jcat.2017.11.017.
- (37) Wang, T.; Xu, W. C.; Wang, H. X. Ternary NiCoFe Layered Double Hydroxide Nanosheets Synthesized by Cation Exchange Reaction for Oxygen Evolution Reaction. *Electrochim Acta* **2017**, *257*, 118-127. DOI: 10.1016/j.electacta.2017.10.074.
- (38) Liu, H.; Wang, Y.; Lu, X.; Hu, Y.; Zhu, G.; Chen, R.; Ma, L.; Zhu, H.; Tie, Z.; Liu, J.; et al. The effects of Al substitution and partial dissolution on ultrathin NiFeAl ternary layered double hydroxide nanosheets for oxygen evolution reaction in alkaline solution. *Nano Energy* **2017**, *35*, 350-357. DOI: 10.1016/j.nanoen.2017.04.011.
- (39) Sumboja, A.; Chen, J.; Zong, Y.; Lee, P. S.; Liu, Z. NiMn layered double hydroxides as efficient electrocatalysts for the oxygen evolution reaction and their application in rechargeable Zn-air batteries. *Nanoscale* **2017**, *9* (2), 774-780. DOI: 10.1039/c6nr08870h.
- (40) Li, P.; Duan, X.; Kuang, Y.; Li, Y.; Zhang, G.; Liu, W.; Sun, X. Tuning Electronic Structure of NiFe Layered Double Hydroxides with Vanadium Doping toward High Efficient Electrocatalytic Water Oxidation. *Advanced Energy Materials* **2018**, *8* (15). DOI: 10.1002/aenm.201703341.
- (41) Zhou, Q.; Chen, Y.; Zhao, G.; Lin, Y.; Yu, Z.; Xu, X.; Wang, X.; Liu, H. K.; Sun, W.; Dou, S. X. Active-Site-Enriched Iron-Doped Nickel/Cobalt Hydroxide Nanosheets for Enhanced Oxygen Evolution Reaction. *ACS Catalysis* **2018**, *8* (6), 5382-5390. DOI: 10.1021/acscatal.8b01332.
- (42) Ng, J. W. D.; García-Melchor, M.; Bajdich, M.; Chakthranont, P.; Kirk, C.; Vojvodic, A.; Jaramillo, T. F. Gold-supported cerium-doped NiO<sub>x</sub> catalysts for water oxidation. *Nature Energy* **2016**, *1* (5). DOI:

10.1038/nenergy.2016.53.

(43) Anantharaj, S.; Karthick, K.; Venkatesh, M.; Simha, T. V. S. V.; Salunke, A. S.; Ma, L.; Liang, H.; Kundu, S.

Enhancing electrocatalytic total water splitting at few layer Pt-NiFe layered double hydroxide interfaces. *Nano Energy* **2017**, *39*, 30-43. DOI: 10.1016/j.nanoen.2017.06.027.

(44) Fan, K.; Chen, H.; Ji, Y.; Huang, H.; Claesson, P. M.; Daniel, Q.; Philippe, B.; Rensmo, H.; Li, F.; Luo, Y.; et al.

Nickel-vanadium monolayer double hydroxide for efficient electrochemical water oxidation. *Nat Commun* **2016**, *7*, 11981. DOI: 10.1038/ncomms11981.

(45) Zhao, Y.; Jia, X.; Chen, G.; Shang, L.; Waterhouse, G. I.; Wu, L. Z.; Tung, C. H.; O'Hare, D.; Zhang, T. Ultrafine NiO

Nanosheets Stabilized by TiO<sub>2</sub> from Monolayer NiTi-LDH Precursors: An Active Water Oxidation Electrocatalyst. *J Am Chem Soc* **2016**, *138* (20), 6517-6524. DOI: 10.1021/jacs.6b01606.

(46) Xiong, X.; Ji, Y.; Xie, M.; You, C.; Yang, L.; Liu, Z.; Asiri, A. M.; Sun, X. MnO<sub>2</sub>-CoP<sub>3</sub> nanowires array: An efficient electrocatalyst for alkaline oxygen evolution reaction with enhanced activity. *Electrochemistry Communications* **2018**, *86*, 161-165. DOI: 10.1016/j.elecom.2017.12.008.

(47) Gao, T.; Jin, Z.; Liao, M.; Xiao, J.; Yuan, H.; Xiao, D. A trimetallic V-Co-Fe oxide nanoparticle as an efficient and stable electrocatalyst for oxygen evolution reaction. *Journal of Materials Chemistry A* **2015**, *3* (34), 17763-17770. DOI: 10.1039/c5ta04058b.

(48) Liu, W.; Du, K.; Liu, L.; Zhang, J.; Zhu, Z.; Shao, Y.; Li, M. One-step electroreductively deposited iron-cobalt composite films as efficient bifunctional electrocatalysts for overall water splitting. *Nano Energy* **2017**, *38*, 576-584. DOI: 10.1016/j.nanoen.2016.11.047.

(49) Liu, Y.; Li, J.; Li, F.; Li, W.; Yang, H.; Zhang, X.; Liu, Y.; Ma, J. A facile preparation of CoFe<sub>2</sub>O<sub>4</sub> nanoparticles on polyaniline-functionalised carbon nanotubes as enhanced catalysts for the oxygen evolution reaction. *Journal of Materials Chemistry A* **2016**, *4* (12), 4472-4478. DOI: 10.1039/c5ta10420c.

(50) He, K.; Cao, Z.; Liu, R.; Miao, Y.; Ma, H.; Ding, Y. In situ decomposition of metal-organic frameworks into ultrathin nanosheets for the oxygen evolution reaction. *Nano Research* **2016**, *9* (6), 1856-1865. DOI: 10.1007/s12274-016-1078-x.

(51) Wang, J. H.; Li, L. P.; Li, J.; Meng, L. S.; Xue, C. L.; Li, G. S. Stabilizing Co<sup>4+</sup> Ions in Ultrathin Cobalt Oxide Nanosheets for Efficient Oxygen Evolution Reaction. *Chemcatchem* **2018**, *10* (21), 4902-4907. DOI: 10.1002/cctc.201801253.

(52) Zhang, B.; Zheng, X. L.; Voznyy, O.; Comin, R.; Bajdich, M.; Garcia-Melchor, M.; Han, L. L.; Xu, J. X.; Liu, M.;

Zheng, L. R.; et al. Homogeneously dispersed multimetal oxygen-evolving catalysts. *Science* **2016**, *352* (6283), 333-

337. DOI: 10.1126/science.aaf1525.

(53) Liu, R.; Wang, Y.; Liu, D.; Zou, Y.; Wang, S. Water-Plasma-Enabled Exfoliation of Ultrathin Layered Double Hydroxide Nanosheets with Multivacancies for Water Oxidation. *Adv Mater* **2017**, *29* (30). DOI: 10.1002/adma.201701546.

(54) Yu, L.; Yang, J. F.; Guan, B. Y.; Lu, Y.; Lou, X. W. D. Hierarchical Hollow Nanoprisms Based on Ultrathin Ni-Fe Layered Double Hydroxide Nanosheets with Enhanced Electrocatalytic Activity towards Oxygen Evolution. *Angew Chem Int Ed Engl* **2018**, *57* (1), 172-176. DOI: 10.1002/anie.201710877.

(55) Huang, J.; Chen, J.; Yao, T.; He, J.; Jiang, S.; Sun, Z.; Liu, Q.; Cheng, W.; Hu, F.; Jiang, Y.; et al. CoOOH Nanosheets with High Mass Activity for Water Oxidation. *Angew Chem Int Ed Engl* **2015**, *54* (30), 8722-8727. DOI: 10.1002/anie.201502836.

(56) Wang, H.; Lee, H. W.; Deng, Y.; Lu, Z.; Hsu, P. C.; Liu, Y.; Lin, D.; Cui, Y. Bifunctional non-noble metal oxide nanoparticle electrocatalysts through lithium-induced conversion for overall water splitting. *Nat Commun* **2015**, *6*, 7261. DOI: 10.1038/ncomms8261.

(57) Huo, M.; Yang, Z.; Yang, C.; Gao, Z.; Qi, J.; Liang, Z.; Liu, K.; Chen, H.; Zheng, H.; Cao, R. Hierarchical Zn-Doped CoO Nanoflowers for Electrocatalytic Oxygen Evolution Reaction. *ChemCatChem* **2019**, *11* (5), 1480-1486. DOI: 10.1002/cctc.201801908.

(58) Saha, S.; Ganguli, A. K. FeCoNi Alloy as Noble Metal-Free Electrocatalyst for Oxygen Evolution Reaction (OER). *ChemistrySelect* **2017**, *2* (4), 1630-1636. DOI: 10.1002/slct.201601243.

(59) Wei, P.; Hao, Z.; Kang, H.; Yang, Guo, D.; Liu, L. Cost-effective and Efficient Catalyst of Bimetallic Nickel Iron Selenide toward Oxygen Evolution Reaction. *ChemCatChem* **2020**, *12* (17), 4416-4421. DOI: 10.1002/cctc.202000345.

(60) Dong, C.; Yuan, X.; Wang, X.; Liu, X.; Dong, W.; Wang, R.; Duan, Y.; Huang, F. Rational design of cobalt-chromium layered double hydroxide as a highly efficient electrocatalyst for water oxidation. *Journal of Materials Chemistry A* **2016**, *4* (29), 11292-11298. DOI: 10.1039/c6ta04052g.

(61) Song, F.; Hu, X. Ultrathin cobalt-manganese layered double hydroxide is an efficient oxygen evolution catalyst. *J Am Chem Soc* **2014**, *136* (47), 16481-16484. DOI: 10.1021/ja5096733.

(62) Yang, F.; Sliozberg, K.; Sinev, I.; Antoni, H.; Bahr, A.; Ollegott, K.; Xia, W.; Masa, J.; Grunert, W.; Cuenya, B. R.; et al. Synergistic Effect of Cobalt and Iron in Layered Double Hydroxide Catalysts for the Oxygen Evolution Reaction. *ChemSusChem* **2017**, *10* (1), 156-165. DOI: 10.1002/cssc.201601272.

(63) Zhang, X.; An, L.; Yin, J.; Xi, P.; Zheng, Z.; Du, Y. Effective Construction of High-quality Iron Oxy-hydroxides and

Co-doped Iron Oxy-hydroxides Nanostructures: Towards the Promising Oxygen Evolution Reaction Application.

*Sci Rep* **2017**, 7, 43590. DOI: 10.1038/srep43590.